



SKECHERS FIT GUIDE

1. Place foot on the measuring guide (without shoe).
2. Make sure instep (inside of foot) is on the line.
3. If the outside of foot is in the blue "wide" area, a wide shoe may provide greater comfort.
4. If the outside of foot exceeds the blue "wide" area, a wide shoe is recommended.
5. Once you know your size, use our easy Shop by Size tool to view all styles in your size!
(Click through from the size chart page)

KIDS'
SIZE GUIDE
Wide width available for boys only.

6	6	Grade School size 5 1/2- 6	TRY WIDE WIDTH If your RIGHT FOOT occupies this grey area.
5	5		
4	4		
3	3		
2	2		
1	1		
13	13	Pre School size 10 1/2- 3	TRY WIDE WIDTH If your RIGHT FOOT occupies this grey area.
12	12		
11	11		
10	10	Toddler size 4 1/2- 10	TRY WIDE WIDTH If your RIGHT FOOT occupies this grey area.
9	9		
8	8		
7	7		
6	6		
5	5		

TRY WIDE WIDTH If your RIGHT FOOT occupies this grey area.

TRY WIDE WIDTH If your RIGHT FOOT occupies this grey area.

TRY WIDE WIDTH If your RIGHT FOOT occupies this grey area.

Tape page 1 to page 2 (align A with B)




Tape page 1 to page 2 (align C with D)



Tape page 1
to page 2
(align A with B)

Tape page 1
to page 2
(align C with D)



KID'S SIZES

PRE/GRADE SCHOOL

*On our site, pre/grade school shoes are designated by an "L" next to the size.

US*	10.5	11	11.5	12	12.5	13	13.5	1	1.5	2	2.5	3	3.5	4	4.5	5	5.5	6
UK	9.5	10	10.5	11	11.5	12	12.5	13	13.5	1	1.5	2	2.5	3	3.5	4	4.5	5
EURO	27	27.5	28	28.5	29	30	31	32	33	33.5	34	35	35.5	36	36.5	37	37.5	38

KID'S SIZES

INFANT/TODDLER

*On our site, infant/toddler shoes are designated by an "N" next to the size.

US*	1	2	2.5	3	3.5	4	4.5	5	5.5	6	6.5	7	7.5	8	8.5	9	9.5	10
UK	0	1	1.5	2	2.5	3	3.5	4	4.5	5	5.5	6	6.5	7	7.5	8	8.5	9
EURO	16	17	18	18.5	19	19.5	20	20.5	21	21.5	22	22.5	23	24	25	25.5	26	26.5

Print Size: 8.5" x 11" at 100%